

Marc / Rian Heated Towel Rail Installation Manual



MYLIFE®

**THIS PRODUCT MUST BE INSTALLED
BY A LICENSED PLUMBER**



PRE-INSTALLATION CHECKS

- Check that the heated towel rail is compatible with your current requirements.
- Before installing the heated towel rail, please make sure you have received all items and that they are undamaged. Any damage claims after installation will not be accepted.
- Check that the floor and wall are level and perpendicular.
- Shut off the main water supply.
- Please check for any hidden pipes and cables, electric or otherwise before drilling holes in a wall.
- Note: Please note due to manufacturing tolerances pipe centres may vary by +/- 10mm, we recommend that pipe work is not altered until your towel rail / radiator is on site.

TOWEL BAR INSTALLATION


Important: Attach the towel bar to the radiator before mounting the radiator on the wall.

1. Determine the desired vertical position for the towel bar and ensure it is horizontally centred on the radiator.
2. Using the holes in the towel bar as guides, drill 2mm pilot holes in the back of the radiator. Note: These models have hollow panels which do not contain any liquids.
3. Secure the towel bar to the radiator by screwing the provided self-tapping screws through the towel bar holes. Ensure the screws do not protrude through the front panel.
4. Tighten the screws securely.




Drill 2mm pilot holes & screw towel bar to rear of radiator.


RADIATOR INSTALLATION



1
Position the towel rail in the desired location, ensure it is level and mark 4 equal positions for the brackets



2
Drill holes in the wall and insert rawl plugs. For false or studded walls you may require different fixings (not supplied).



3
Insert the screws through the bracket holes & secure them to the wall by screwing into the rawl plugs. Use a spirit level to re-check that the brackets are level


Marc / Rian Heated Towel Rail Installation Manual



RADIATOR INSTALLATION

4


Wrap PTFE tape around the blanking plug and air vent threads before installing into the top of the radiator. Carefully tighten with a spanner, avoid damaging the finish.



Once the towel rail is completely installed follow the after installation instructions to let the air out.

5

Hang the radiator on the brackets, ensuring that the radiator sits fully on all brackets. Then connect both flow and return pipework as required.



AFTER INSTALLATION

- Use a screwdriver to open the air vent, open the valve and let water rush into the towel rail. Check all connections for leaks.
- Once water overflows from the air vent, there is no air in the towel rail.
- Use a screwdriver to close the air vent, turn on the valve and the towel warmer is ready for use.

CARE INSTRUCTIONS

- Do not use abrasive cleaners or scouring pads to clean the heated towel rail as they may scratch and dull the surface.
- Use warm soapy water or liquid detergent to clean the surface and dry with a soft cloth.

TROUBLESHOOTING

Problem	Cause	Solution
Cold spots on the radiator	Water is not flowing through the radiator properly	Check to make sure there is no trapped air inside the radiator. "Bleed" the radiator to release trapped air
Leaking Radiator	Plug or valve is loose	Tighten the plugs or valves
Sound of whistling or water whooshing	Radiator was not perfectly balanced when it was installed	Re-balance all radiators on the heating system
Clanking sound	The radiator was installed in a space that does not allow for pipe expansion	Re-check pipework

AFTER SALES & TECHNICAL SUPPORT

Our highly experienced after sales & technical support team are always on hand to help should you require technical advise or a spare part. T: +44 (0)28 3025 9988 - E: technical@mylifebathrooms.com